

Figure 1




Figure 2

400

22-141 50 SHEETS 22-142 100 SHEETS 22-144 200 SHEETS






Figure 3

START 401 RMS sets up routing tables and QoS parameters for each flow 402 Monitor congestion on each segment of the MPTR Allocate available bandwidth Decreasing Status of BW, Increasing Is BWT approaching
BWMax 406 Guaranteed Qos flows 407 Deallocate available bandwidth of upstream

Figure 4




Figure 5




Figure 6.